



CSP SPORTS AND REC

A division of Child Safe Products, Inc.

550 Main Street, Westbury, NY 11590 | P. 516. 848. 7773

PREVENTIVE MAINTENANCE GUIDE

Tennis/Basketball Surface

We recommend the following procedures to care for, and extend the life of your new Tennis/Basketball surface.

SWEEPING

Remove leaves, pine needles and any other debris from the court. This should be done so with a horsehair broom.

WASHING

It is important to clean your court regularly. Once a month is recommended. Clean with clean potable water and dish washing liquid. Dove is a recommended brand. Rain showers can help clean your court, however, birdbaths can form and accumulate dirt, which in result can stain the court. Remove water from birdbaths as often as possible.

PROHIBITED FOR DAMAGE PREVENTION

Please make sure there is no skateboard, roller blading and bike use on the court. No Food/Drink. No Gum. Do not drag benches, chairs, or other items on the court. Anchoring benches or chairs to the court can prevent damage from sliding and scraping.

LANDSCAPING

Keep grass/ trimmed grass away from court. Protect the court surface from weed killer, insect prevention products, fertilizer and other chemical products that could potentially damage the court.

SNOW REMOVAL

No mechanical/plow for snow removal allowed. It can result in damage to the court.

***Remove tensions of the nets during the winter month (December).*